

 **419-480-9118**
 **cs@toledo-tools.com**
 **www.toledo-tools.com**

TOLEDO TOOLS

PRODUCT CATALOG

Toledo Tools

Toledo, Ohio 43614
United States

419-480-9118 
cs@toledo-tools.com 

TOLEDO PIPE 59832 DIE HEAD POST FITS RIDGID® 811A DIE HEAD 97065

SKU: TP-59832

PRICE: \$12.99



PRODUCT DESCRIPTION

Toledo Pipe Tools® is proud to give you alternative high quality replacement parts.

Replacement Die Head Post fits RIDGID® die heads.

- Fits RIDGID® 811A 1/8"-2" NPT Universal Die Head Quick Opening RH 97065
- Fits RIDGID® 842 1/8"-2" NPT Quick Opening Universal Die Head LH 23282
- Fits RIDGID® 555 1/8"-3/4" Dual Die Head, Quick Opening, RH 10491
- Fits RIDGID® 531 1/4"-1" Bolt Die Head Quick Opening RH/LH 97045
- Fits RIDGID® 532 1-1/8"-2" Bolt Die Head Quick Opening RH/LH 97050
- Fits RIDGID® 811A 1/8"-2" BSPT Universal Die Head Quick Opening RH 97070
- Fits RIDGID® 500A 1/8" Mono RH Quick Opening Die Head 42047
- Fits RIDGID® 500A 1/4" Mono RH Quick Opening Die Head 42052
- Fits RIDGID® 500A 3/8" Mono RH Quick Opening Die Head 42057
- Fits RIDGID® 500A 1/2" Mono RH Quick Opening Die Head 42062
- Fits RIDGID® 500A 3/4" Mono RH Quick Opening Die Head 42067
- Fits RIDGID® 500A 1" Mono RH Quick Opening Die Head 42072
- Fits RIDGID® 500A 1-1/4" Mono RH Quick Opening Die Head 42077
- Fits RIDGID® 500A 1-1/2" Mono RH Quick Opening Die Head 42082
- Fits RIDGID® 500A 2" Mono RH Quick Opening Die Head 42087
- Replaces RIDGID® Part: 59832

**ADDITIONAL
INFORMATION**

More Information

Manufacturer

Toledo Pipe Tools

Description

Toledo Pipe Tools® is proud to give you alternative high quality replacement parts. Replacement Die Head Post fits RIDGID® die heads.

- Fits RIDGID® 811A 1/8"-2" NPT Universal Die Head Quick Opening RH 97065
- Fits RIDGID® 842 1/8"-2" NPT Quick Opening Universal Die Head LH 23282
- Fits RIDGID® 555 1/8"-3/4" Dual Die Head, Quick Opening, RH 10491
- Fits RIDGID® 531 1/4"-1" Bolt Die Head Quick Opening RH/LH 97045
- Fits RIDGID® 532 1-1/8"-2" Bolt Die Head Quick Opening RH/LH 97050
- Fits RIDGID® 811A 1/8"-2" BSPT Universal Die Head Quick Opening RH 97070
- Fits RIDGID® 500A 1/8" Mono RH Quick Opening Die Head 42047
- Fits RIDGID® 500A 1/4" Mono RH Quick Opening Die Head 42052
- Fits RIDGID® 500A 3/8" Mono RH Quick Opening Die Head 42057
- Fits RIDGID® 500A 1/2" Mono RH Quick Opening Die Head 42062
- Fits RIDGID® 500A 3/4" Mono RH Quick Opening Die Head 42067
- Fits RIDGID® 500A 1" Mono RH Quick Opening Die Head 42072
- Fits RIDGID® 500A 1-1/4" Mono RH Quick Opening Die Head 42077
- Fits RIDGID® 500A 1-1/2" Mono RH Quick Opening Die Head 42082
- Fits RIDGID® 500A 2" Mono RH Quick Opening Die Head 42087
- Replaces RIDGID® Part: 59832



419-480-9118



cs@toledo-tools.com



www.toledo-tools.com

TOLEDO TOOLS