

 **419-480-9118**  
 **cs@toledo-tools.com**  
 **www.toledo-tools.com**

**TOLEDO TOOLS**

## PRODUCT CATALOG

**Toledo Tools**

Toledo, Ohio 43614  
United States

419-480-9118   
cs@toledo-tools.com 

## TOLEDO PIPE 97075 815A SELF OPENING DIE HEAD FITS RIDGID® 300 535 1822 PIPE THREADERS

**SKU: TP-815A**

**PRICE: \$249.99**



### PRODUCT DESCRIPTION

The Toledo Pipe Tools® 815A Universal Self-Opening Die Head will automatically open after completion of threading. This oiling die head will thread 1/8-inch to 2-inch pipe and 1/4-inch to 2-inch bolts. The Toledo Pipe Tools® 815A Die Head is for use with RIDGID® Universal Right-Hand Dies. This die head will fit compatible RIDGID® pipe threading machines.

- Die head opens automatically after completion of threading.
- Fits RIDGID® Universal Right-Hand Dies.
- Pipe Capacity: 1/8 in. to 2 in.
- Bolt Capacity: 1/4 in. to 2 in.
- Fits RIDGID® 300, 300 Compact, 535, 535A, 1822.
- Replaces Part Number: 97075

### ADDITIONAL INFORMATION

[More Information](#)

**Manufacturer** Toledo Pipe Tools

The Toledo Pipe Tools® 815A Universal Self-Opening Die Head will automatically open after completion of threading. This oiling die head will thread 1/8-inch to 2-inch pipe and 1/4-inch to 2-inch bolts. The Toledo Pipe Tools® 815A Die Head is for use with RIDGID® Universal Right-Hand Dies. This die head will fit compatible RIDGID® pipe threading machines.

**Description**

- Die head opens automatically after completion of threading.
- Fits RIDGID® Universal Right-Hand Dies.
- Pipe Capacity: 1/8 in. to 2 in.
- Bolt Capacity: 1/4 in. to 2 in.
- Fits RIDGID® 300, 300 Compact, 535, 535A, 1822.
- Replaces Part Number: 97075

 **419-480-9118**

 **cs@toledo-tools.com**

 **www.toledo-tools.com**

**TOLEDO TOOLS**